






damage both the breech itself and the magwell.
















Check the hole in MagReleaseR for obstructions or burrs and remove them if present. Line up the hole in it with the indicated hole in the RivalLower. Insert a Short Pin through the RivalLower and into the MagReleaseR. You can use an extra Short Pin and a Hammer to push it into place. Use a 4-40 screw and a screwdriver to plug the open hole. Repeat for the opposite side of the RivalLower.





































Slide the foregrip back to compress the mainspring until the plunger gets engaged on the Sear. Inssert a Magazine loaded with Rival Rounds. Slide the foregrip all the way forwards to chamber the Rival Round in the top of the Magazine. You can load up to three HIRs into the barrel at a time if desired by cycling the Foregrip back and forth multiple times prior to pulling the Trigger. ONLY PULL THE TRIGGER WHEN THE BREECH IS CLOSED AND THE FOREGRIP IS IN THE FORWARD POSITION. If you do not have a Rival Round loaded in the barrel and need to pull the Trigger to de-prime the blaster, do so with the breech completely OPEN while firmly grasping the foregrip. Hold the trigger down, then slowly close the breech by moving the foregrip forwards.

Replacing the Main Spring does not require full disassembly of the Blaster. You just need to reverse the last 2 steps in these instructions in order to take the buttplate off.

The Blaster and Hardware Kits are shipped with a K25 spring. The alternate spring options are the 788 and K25 which have to be purchased separately or opted for as a replacement.





More accessories to be added in due time.